




REFRIGERATION AND
AIR CONDITIONING


Instructions Battery module type EKA 181A, 181C

084R9988

084R9988




EKA 181A
Battery module + Buzzer



EKA 181C
Battery module

1) Power off

2)



Danfoss
84R225.15.10

EKC 202
EKC 204
AK-CC 210

3) Power on