



AKVA 10




Description	Qty	Code no.
Orifice 10-1		068F0526
Orifice 10-2		068F0527
Orifice 10-3		068F0528
Orifice 10-4		068F0529
Orifice 10-5		068F0530
Orifice 10-6		068F0531
Orifice 10-7		068F0532
Pos. 7 Orifice	1	
4 Alu gasket	1	
Filter		068F0540
Pos. 6 Filter	10	
4 Alu gasket	10	
Armature set		068F5045
Pos. 1 Armature	1	
3 Armature tube assembly	1	
4 Alu gasket	1	

AKVA 15



Description	Qty	Code no.
Piston kit, AKVA 15-1		068F5265
Piston kit, AKVA 15-2		068F5266
Piston kit, AKVA 15-3		068F5267
Piston kit, AKVA 15-4		068F5268
Pos. 5 Piston assembly	1	
7 Square gasket, rubber	1	
8 O-ring	1	
15 Spring	1	
16 Insert	1	
19 Label	1	
Orifice set		068F5261
Pos. 22 Main orifice	1	
11 Pilot orifice	1	
21 Alu gasket	1	
8 O-ring	1	
7 Square gasket, rubber	1	
Armature set		068F5045
Pos. 17 Armature	1	
18 Armature tube assembly	1	
12 Alu gasket	1	
Filter		068F0540
Pos. 10 Filter	10	
12 Alu gasket	10	
Gasket set		068F5264
Pos. 8 O-ring	10	
13 O-ring	10	
12 Alu gasket	10	
21 Alu gasket	10	
7 Square gasket, rubber	10	

AKVA 20



Description	Qty	Code no.
Piston kit		
AKVA 20-0.6		042H2039
AKVA 20-1		042H2040
AKVA 20-2		042H2041
AKVA 20-3		042H2042
AKVA 20-4		042H2043
AKVA 20-5		042H2044
Pos. 10 Piston assembly	1	
11 Spring	1	
27 Insert	1	
14 O-ring	1	
3 O-ring	2	
Orifice kit		068F5270
for AKVA 20-0.6, AKVA 20-1, AKVA 20-2, AKVA 20-3		
Pos. 13 Main orifice, dia. 8 mm	1	
18 Pilot orifice, dia. 1.2 mm	1	
16 Pin	1	
3 O-ring	2	
14 O-ring	1	
17 Alu gasket	1	
Orifice kit		068F5271
for AKVA 20-4, AKVA 20-5		
Pos. 13 Main orifice, dia. 14 mm	1	
18 Pilot orifice, dia. 2.4 mm	1	
16 Pin	1	
3 O-ring	2	
14 O-ring	1	
17 Alu gasket	1	
Seal kit		042H0160
Pos. 3 O-ring	2	
14 O-ring	1	
25 O-ring	1	
5 Alu gasket	2	
17 Alu gasket	1	
Armature set		068F5045
Pos. 20 Armature	1	
19 Armature tube assembly	1	
5 Alu gasket	1	